

6Cyl Full Seq High Imp Dual Injector

Last Changed: 22/10/2025

Harness Required: M63-P3

A

B

C

D

E

F

Write your firing order from left to right in the blocks above marked with an alphabetical letter. Then write the corresponding number on the corresponding injector with the same alphabetical letter in the drawing below. Do it for both sets of injectors. Now connect your injector number to the corresponding colour wire.

Note: The order of the injectors will differ on their placing on the engine, as long as it is connected to the same colour wire as this illustration. Each secondary injector requires a 3A diode to prevent feadback current when the relay is off. Do the same procedure for the straight six engine,

