

| Callisto                            | RacePack | Comercial | Notes |
|-------------------------------------|----------|-----------|-------|
| Tuning Software                     |          |           |       |
| Hyperspace                          |          |           |       |
| EeziTune                            | X        | X         |       |
| Inputs                              |          |           |       |
| Map Sensor                          | X        | X         |       |
| TPS Sensor                          | X        | X         |       |
| Water Temperature Sensor            | X        | X         |       |
| Air Temperature Sensor              | X        | X         |       |
| Lambda Sensor                       | X        | X         |       |
| Altitude Sensor OnBoard             | X        | X         | *     |
| Altitude Sensor External            |          |           |       |
| Map used as Altitude Sensor         | X        | X         |       |
| POT Sensor                          | X        |           |       |
| Fuel Pressure Sensor                |          |           |       |
| Digital Switch                      | X        |           |       |
| Crank TDC Sensor                    | X        | X         |       |
| Cam Home Sensor                     | X        | X         | !     |
| Cam1 VVTI Sensor                    | X        | X         |       |
| Cam2 VVTI Sensor                    | X        | X         |       |
| Outputs                             |          |           |       |
| HV Negative Drivers (above 300V)    | 12       | 12        |       |
| MV Negative Drivers (up to 100V)    |          |           |       |
| LV Negative Drivers (up to 40V)     | 2        | 2         |       |
| LV Positive Drivers                 | 6        | 6         |       |
| Features                            |          |           |       |
| Full Sequential Spark               | X        |           | @     |
| Wasted Spark                        | X        | X         |       |
| Dual Distributor                    | X        | X         |       |
| Distributor                         | X        | X         |       |
| Basic Coil Drivers                  | 12       | 12        | %     |
| Smart Coil Drivers                  | 6        | 6         |       |
| Full Sequential Injection           | X        |           |       |
| Split Sequential Injection          | X        | X         |       |
| Injector Trimming                   | 8        |           | %     |
| Fuel Pressure Control               |          |           |       |
| Dual Injectors Ratio Method         | X        |           | @     |
| Dual Injectors Graph Method         | X        |           | @     |
| Injection Angle Adjustments         | X        | X         | ^     |
|                                     |          |           |       |
| Automatic Torque Control            | X        | X         |       |
| Spinning Control                    | X        |           |       |
| Launch Control                      | X        |           |       |
| Launch Retard to -30° Gear Triggers | X        |           |       |
| Launch Retard to 0°                 | X        |           |       |
| Launch Recover Delay                | X        |           |       |
| Anti-Lag control                    | X        |           |       |
| Dual Maps                           | X        |           |       |
| RapidFire                           | X        |           |       |
| Flat-Shift control                  | X        |           |       |
| POT Input                           | X        |           |       |
| TuneBox Capable                     | X        |           |       |
|                                     |          |           |       |
| Open Loop Cam Control               | X        | X         |       |
| Intake Flap Control                 | X        |           |       |
| GP Outputs                          | 6        | 2         | %     |
|                                     |          |           |       |
| Android Pack                        | X        | X         | &     |

|                         |   |   |    |
|-------------------------|---|---|----|
| Lambda Control          | X | X | #  |
| Idle Control            | X | X | \$ |
| V-Tech / Intake Flap    | X | X |    |
|                         |   |   |    |
| TPS Compensation Graph  | X |   |    |
| Water Temp Compensation | X | X |    |
| Air Temp Compensation   | X | X |    |
| Lambda Control          | X | X | #  |
| Idle Control            | X | X | %  |
| Altitude Compensation   | X | X | *  |
| Fuel Pressure Control   |   |   |    |

| The Badger                          | RacePack | BaseLine | Notes |
|-------------------------------------|----------|----------|-------|
| Tuning Software                     |          |          |       |
| Hyperspace                          |          |          |       |
| EeziTune                            | X        | X        |       |
| Inputs                              |          |          |       |
| Map Sensor                          | X        | X        |       |
| TPS Sensor                          | X        | X        |       |
| Water Sensor                        | X        | X        |       |
| Air Sensor                          | X        | X        |       |
| Lambda Sensor                       | X        |          |       |
| Altitude Sensor OnBoard             | X        | X        | *     |
| Altitude Sensor External            |          |          |       |
| Map used as Altitude Sensor         | X        | X        |       |
| POT Sensor                          | X        |          |       |
| Fuel Pressure Sensor                |          |          |       |
| Digital Switch                      | X        |          |       |
| Crank TDC Sensor                    | X        | X        |       |
| Cam Home Sensor                     | X        | X        | !     |
| Cam1 VVTI Sensor                    | X        |          |       |
| Cam2 VVTI Sensor                    | X        |          |       |
| Outputs                             |          |          |       |
| HV Negative Drivers (above 300V)    | 8        | 8        |       |
| MV Negative Drivers (up to 100V)    |          |          |       |
| LV Negative Drivers (up to 40V)     | 2        | 2        |       |
| LV Positive Drivers                 |          |          |       |
| Features                            |          |          |       |
| Full Sequential Spark               |          |          |       |
| Wasted Spark                        | X        | X        |       |
| Dual Distributor                    | X        | X        |       |
| Distributor                         | X        | X        |       |
| Basic Coil Drivers                  | 8        | 8        | %     |
| Smart Coil Drivers                  |          |          |       |
| Full Sequential Injection           |          |          |       |
| Split Sequential Injection          | X        | X        |       |
| Injector Trimming                   |          |          |       |
| Fuel Pressure Control               |          |          |       |
| Dual Injectors Ratio Method         |          |          |       |
| Dual Injectors Graph Method         |          |          |       |
| Injection Angle Res. °              | X        | X        | ^     |
|                                     |          |          |       |
| Automatic Torque Control            | X        |          |       |
| Spinning Control                    | X        |          |       |
| Launch Control                      | X        | B        |       |
| Launch Retard to -30° Gear Triggers | X        |          |       |
| Launch Retard to 0°                 | X        |          |       |
| Launch Recover Delay                | X        |          |       |
| Anti-Lag control                    | X        |          |       |
| Dual Maps                           |          |          |       |
| RapidFire                           | X        |          |       |
| Flat-Shift control                  | X        |          |       |
| POT Input                           | X        |          |       |
| TuneBox Capable                     | X        |          |       |
|                                     |          |          |       |
| Open Loop Cam Control               | X        |          |       |
| Intake Flap Control                 |          |          |       |
| GP Outputs                          | 2        | 2        | %     |
|                                     |          |          |       |
| Android Pack                        | X        | X        | &     |

|                         |   |   |    |
|-------------------------|---|---|----|
| Lambda Control          | X |   | #  |
| Idle Control            | X | V | \$ |
| V-Tech / Intake Flap    | X | X |    |
|                         |   |   |    |
| TPS Compensation Graph  | X |   |    |
| Water Temp Compensation | X | X |    |
| Air Temp Compensation   | X | X |    |
| Lambda Control          | X |   | #  |
| Idle Control            | X | X | %  |
| Altitude Compensation   | X | X | *  |
| Fuel Pressure Control   |   |   |    |

| Mercury3                            | Ultimate | Advance | Intermediat | Notes |
|-------------------------------------|----------|---------|-------------|-------|
| Tuning Software                     |          |         |             |       |
| Hyperspace                          | X        | X       | X           |       |
| Cosmos / EeziTune                   |          |         |             |       |
| Inputs                              |          |         |             |       |
| Map Sensor                          | X        | X       | X           |       |
| TPS Sensor                          | X        | X       | X           |       |
| Water Sensor                        | X        | X       | X           |       |
| Air Sensor                          | X        | X       | X           |       |
| Lambda Sensor                       | X        | X       | X           |       |
| Altitude Sensor OnBoard             |          |         |             |       |
| Altitude Sensor External            | X        | X       | X           |       |
| Map used as Altitude Sensor         |          |         |             |       |
| POT Sensor                          | X        | X       | X           | %     |
| Fuel Pressure Sensor                | X        | X       |             |       |
| Digital Switch                      | X        | X       | X           | %     |
| Crank TDC Sensor                    | X        | X       | X           |       |
| Cam Home Sensor                     | X        | X       | X           |       |
| Cam1 VVTI Sensor                    | X        | X       | X           |       |
| Cam2 VVTI Sensor                    | X        | X       | X           |       |
| Outputs                             |          |         |             |       |
| HV Negative Drivers (above 300V)    |          |         |             |       |
| MV Negative Drivers (up to 100V)    | 8        | 8       | 8           |       |
| LV Negative Drivers (up to 40V)     | 4        | 4       | 4           |       |
| LV Positive Drivers                 | 8        | 8       | 8           |       |
| Features                            |          |         |             |       |
| Full Sequential Spark               | X        |         |             | @     |
| Wasted Spark                        | X        | X       |             |       |
| Dual Distributor                    | X        | X       |             |       |
| Distributor                         | X        | X       | X           |       |
| Basic Coil Drivers                  |          |         |             |       |
| Smart Coil Drivers                  | 8        | 8       | 8           |       |
| Full Sequential Injection           | X        | X       |             |       |
| Split Sequential Injection          | X        | X       | X           |       |
| Injector Trimming                   | 8        |         |             |       |
| Fuel Pressure Control               | X        | X       |             |       |
| Dual Injectors Ratio Method         | X        | X       |             | %     |
| Dual Injectors Graph Method         | X        | X       |             | %     |
| Injection Angle Res. °              | X        | X       |             | ^     |
|                                     |          |         |             |       |
| Automatic Torque Control            | X        | X       |             |       |
| Spinning Control                    |          |         |             |       |
| Launch Control                      | X        | X       | X           |       |
| Launch Retard to -30° Gear Triggers | X        |         |             |       |
| Launch Retard to 0°                 | X        | X       | X           |       |
| Launch Recover Delay                | X        |         |             |       |
| Anti-Lag control                    | X        | X       |             |       |
| Dual Maps                           | X        | X       | X           |       |
| RapidFire                           | X        | X       | X           |       |
| Flat-Shift control                  | X        | X       |             |       |
| POT Input                           | X        | X       | X           |       |
| TuneBox Capable                     |          |         |             |       |
|                                     |          |         |             |       |
| Open Loop Cam Control               | X        | X       | X           |       |
| Intake Flap Control                 | X        | X       | X           |       |
| GP Outputs                          | 10       | 10      | 2           | %     |
|                                     |          |         |             |       |
| Android Pack                        | X        | X       | X           | &     |

|                         |   |   |   |    |
|-------------------------|---|---|---|----|
| Lambda Control          | X | X | X | #  |
| Idle Control            | X | X | X | \$ |
| V-Tech / Intake Flap    | X | X | X |    |
|                         |   |   |   |    |
| TPS Compensation Graph  | X | X | X |    |
| Water Temp Compensation | X | X | X |    |
| Air Temp Compensation   | X | X | X |    |
| Lambda Control          | X | X | X | #  |
| Idle Control            | X | X | X | %  |
| Altitude Compensation   | X | X | X | *  |
| Fuel Pressure Control   | X | X |   |    |

# Wide Band Requires External Electronic Converter  
\$ Stepper Motors Requires External Electronic Converter  
V Valve Type Only  
B Button Launch Only  
\* Optional Sensor must be installed if MAP sensor is in use.  
% Dependant on selections as it is shared I/O  
& Requires Activation and BlueTooth Module  
@ Developped on request  
^ Depending on trigger wheel increments  
! RacePack + Firmware Dependant